

# Bikini Trimmer Set

OWNER'S MANUAL model 3882K version 23.04.25

Thank you for purchasing the PALMPERFECT<sup>®</sup> Bikini Trimmer Set. To ensure you have the best possible experience with this product, please read all instructions and precautions carefully before use.

#### WARNING

This device is not a toy and is not intended for use by or on children. This device is intended for household use only. Do not use the device if it has a damaged foil, blade, or cutting unit, as injury may occur. Do not expose the device to direct sunlight, extreme temperatures or heated surfaces. This device is water resistant to IPX4 standards. It can be exposed to splashing water in the shower, and can be rinsed clean under the faucet. The device should not be completely submerged in water.

## **PRODUCT FEATURES**

- 1. Bikini Trimmer
- 2. Foil Shaver
- 3. Trimming Guide
- 4. Twist Attachment Change
- 5. Battery Port & Twist On/Off

### BATTERIES

The trimmer requires one (1) AA 1.5 volt alkaline battery (not included) for operation. Do not use old or damaged batteries.

Battery installation / replacement:

1. Unlock the battery compartment by twisting the handle to the left until the arrows line up and then pulling the cover away from the groomer (Fig. 1).

2. Insert one (1) AA battery into the battery compartment according the polarity markings (+ / - ) indicated within the compartment. The battery should fit snugly into place.

3. Replace the battery compartment cover by lining up the arrows and twisting to the right (Fig. 2).

Note: The device will not operate if the battery is improperly installed. Replace the battery as soon as you notice the device is running slower than normal.

# CHANGING ATTACHMENTS



The Bikini Trimming Set includes a bikini shaver and foil shaver attachments. The attachments can be interchanged easily. Only change attachments with the device powered OFF.

#### Attachment removal / installation

 Twist the attachment head to the right until the arrows line up, and lift it up and away from the device (Fig 3).

2. Position the new attachment so the arrows line up and connect it to the device. Twist to the left to lock it into place (Fig 4).

#### **USING THE TRIMMING GUIDE**

A trimming guide is included for trimming hair to a longer length. The trimming guide shown in Fig. 5 is compatible with the bikini shaver attachment. Only install or remove the guide with the attachment secured to the device. To install the guide, position it over the blades and apply gentle pressure until it snaps into place (Fig. 5). It can be removed by pulling gently away from the blades.

### USING THE TOTAL GROOMING SYSTEM

Power the device ON by twisting the handle to the right. Power the device OFF by twisting the handle to the left. Only operate the device with an attachment securely connected. Never use the device on irritated or damaged skin.







#### Bikini Trimmer:

This attachment can be used with or without the guide attached depending on the desired hair length. For best results, use short, even strokes. Apply only light pressure - it's not necessary to press hard. For sensitive areas use the trimming guide.

#### Foil Shaver:

This attachment can be used to fine hairs. For best results, use small and circular strokes to get the most hair. The foil shaver requires little to no pressure when using.

### CLEANING

Always clean the device with the power turned OFF. You can expose the device to running water for cleaning, but it should never be completely submerged. Wipe with a clean, dry cloth after rinsing. The attachments can be removed for cleaning separately if needed. Shake out any excess debris, and blow or rinse off the cutting assembly.

# **CONTACT/ WARRANTY/ SUPPORT**

The Bikini Trimmer Set carries a warranty against manufacturing defects (excluding cutting blades) for two years from the date of original purchase. Beacon Wellness Brands will, at our option and upon submission of a valid proof of purchase within the warranty period, repair or replace the shaver free of charge. For assistance or for issues related to performance, damages, blade replacement, warranty, regular maintenance or customer feedback, please contact us Toll Free at (800) 514-2546, Monday - Friday from 8:30AM until 5:30PM EST.

Beacon Wellness Brands 85 Wells Ave Suite 106 Newton, MA 02459 USA

© 2023 Beacon Wellness Brands, Inc.